



1/7

FIG. 1



2/7

FIG. 2



3/7

FIG. 3

PC MATERIAL
 $B_m = 0.2T$
 $f = 8Hz$






FIG. 4

PC MATERIAL
 $B_m = 0.2T$
 $f = 8Hz$



4/7

FIG. 5



5/7

FIG. 6

PC MATERIAL
 $B_m = 0.65T$
 $f = 50Hz$





FIG. 7

PC MATERIAL
 $B_m = 0.65T$
 $f = 50Hz$



6/7

FIG. 8

PB MATERIAL
 $B_m = 0.9T$
 $f = 50\text{Hz}$





FIG. 9

PD MATERIAL
 $B_m = 0.9T$
 $f = 50\text{Hz}$



7/7

FIG. 10

PC MATERIAL
 $B_m = 0.65T$
 $f = 100\text{Hz}$

